


Fan-out PPMgSLT

Available for UV, Visible - MIR Range with High Conversion Efficiency

Let's try standard Fan-out PPMgSLT

- ✓ Tunable Laser SHG
- ✓ Tunable OPO/OPG
- ✓ Watt Class Visible Generation
- ✓ Feasibility Test for New Wavelength

Officially Licensed



PPMgSLT (QPM Device)
*QPM: Quasi Phase Matching

Licensed Patents on PPMgSLT
US6211999 / US6673330 / JP4569911



Prices

(JPY)

Standard Type	200,000~ /pc
Additional AR-coating	250,000~ /batch


Volume discount is available!

Application Example



Specification

Type/ ITEM	Thickness (mm)	Periodicity		Phase-matching condition @ around 50°C (SHG wavelength)
		Λa (μm)	Λb (μm)	
A	0.4	5.9	6.5	483~497
B		6.4	7.0	496~509
C		6.9	7.6	508~523
D	0.5	7.5	8.2	522~536
E		8.1	8.9	535~551
F		8.8	9.7	550~568
G		9.6	10.6	567~585
H		10.5	11.6	584~605
I	0.8	11.5	12.7	604~625
J		12.6	13.9	624~647
K		13.8	15.2	646~670
L		15.1	16.7	669~697
M		16.6	18.3	696~725
N		18.2	20.1	724~757
O		20.0	22.1	756~794



notes:

Conversion efficiency of fan-out structure is lower than that of single periodicity devices. It depends on the beam size.

P	1.0	22.0	24.3	793~835
Q		24.2	26.7	834~886
R		26.6	29.4	885~954
S		29.3	32.4	953~1055
T		32.3	35.7	1054~(1255)
U		35.6	39.3	

OXIDE

Oxide Corporation

1747-1 Makihara, Mukawa, Hokuto, Yamanashi 408-0302 JAPAN

Tel: +81-551-26-0022, Fax: +81-551-26-0033


Sales@opt-oxide.com, <http://www.opt-oxide.com>

Contents are things of 1-Feb-2013.

Fan-out PPMgSLT (Common specification)

Item	Specification	Inspection method	Sampling	
1. Material				
1.1	Material	MgO: Stoichiometric LiTaO ₃	—	—
2. Device				
2.1	Length (L1)	11.0mm +/-0.1mm	Measuring microscope	All
2.2	Width of device (W1)	7.0mm +/- 0.1 mm	Measuring microscope	Reference plates only
2.3	Width of periodically poled area (W2)	5.0mm +/-0.1mm	—	—
2.4	Thickness (T1) ^{*1}	0.4 +/-0.05mm 0.5 +/-0.05mm 0.8 +/-0.05mm 1.0 +/-0.05mm	height gauge	Reference plates only
2.5	Flatness [Op] plane	<= λ /10 @ 633nm	Optical interferometer	All
2.6	Flatness [Op'] plane	<= λ /10 @ 633nm	Optical interferometer	All
2.7	Parallelism	<= 5 arc minutes	Autocollimator	All
2.8	Effective aperture (under periodically poled area: (W2 X T1))	>80%	Microscope	All
3. Phase matching condition				
3.1	QPM period ^{*2}	Λ a μ m ~ Λ b μ m (Fan-out)	—	—

Schematics of the device



List of specifications

Type/ ITEM	Thickness T1 ^{*1} (mm)	Periodicity ^{*2}		Phase-matching condition @ around 50°C (SHG wavelength)
		Λ a (μ m)	Λ b (μ m)	
A	0.4	5.9	6.5	483~497
B		6.4	7.0	496~509
C		6.9	7.6	508~523
D	0.5	7.5	8.2	522~536
E		8.1	8.9	535~551
F		8.8	9.7	550~568
G		9.6	10.6	567~585
H		10.5	11.6	584~605
I	0.8	11.5	12.7	604~625
J		12.6	13.9	624~647
K		13.8	15.2	646~670
L		15.1	16.7	669~697
M		16.6	18.3	696~725
N		18.2	20.1	724~757
O		20.0	22.1	756~794
P		1.0	22.0	24.3
Q	24.2		26.7	834~886
R	26.6		29.4	885~954
S	29.3		32.4	953~1055
T	32.3		35.7	1054~
U	35.6		39.3	

OXIDE

Oxide Corporation

1747-1 Makihara, Mukawa, Hokuto, Yamanashi 408-0302 JAPAN


Tel: +81-551-26-0022, Fax: +81-551-26-0033

Sales@opt-oxide.com, <http://www.opt-oxide.com>


Contents are things of 1-Feb-2013.

Fan-out PPMgSLT: Type A, B (Phase matching condition)


EXAMPLE of calculation
(Phase matching at around 50°C)



Type A



Type B



Note:

- Above calculation are based on the following reference paper.
A. Bruner et al., Opt. Lett. Vol. 28, p. 194 (2003).
- Phase matching temperature would be different around $\pm 20^\circ\text{C}$ at visible light region and more at middle infrared region. That is because of the slight differences of refractive index between reference paper and real material. Please ask us detail information.

OXIDE

Oxide Corporation

1747-1 Makihara, Mukawa, Hokuto, Yamanashi 408-0302 JAPAN

Tel: +81-551-26-0022, Fax: +81-551-26-0033


Sales@opt-oxide.com, <http://www.opt-oxide.com>

Contents are things of 1-Feb-2013.


Fan-out PPMgSLT: Type C-H (Phase matching condition)

EXAMPLE of calculation
(Phase matching at around 50°C)


Type C




Type D




Type E




Type F



Type G



Type H



Note:

- Above calculation are based on the following reference paper.
A. Bruner et al., Opt. Lett. Vol. 28, p. 194 (2003).
- Phase matching temperature would be different around $\pm 20^\circ\text{C}$ at visible light region and more at middle infrared region. That is because of the slight differences of refractive index between reference paper and real material. Please ask us detail information.

OXIDE

Oxide Corporation

1747-1 Makihara, Mukawa, Hokuto, Yamanashi 408-0302 JAPAN

Tel: +81-551-26-0022, Fax: +81-551-26-0033


Sales@opt-oxide.com, <http://www.opt-oxide.com>

Contents are things of 1-Feb-2013.


Fan-out PPMgSLT: Type I-N (Phase matching condition)

EXAMPLE of calculation
(Phase matching at around 50°C)


Type I




Type J




Type K




Type L



Type M



Type N



Note:

- Above calculation are based on the following reference paper.
A. Bruner et al., Opt. Lett. Vol. 28, p. 194 (2003).
- Phase matching temperature would be different around $\pm 20^\circ\text{C}$ at visible light region and more at middle infrared region. That is because of the slight differences of refractive index between reference paper and real material. Please ask us detail information.

OXIDE

Oxide Corporation

1747-1 Makihara, Mukawa, Hokuto, Yamanashi 408-0302 JAPAN

Tel: +81-551-26-0022, Fax: +81-551-26-0033


Sales@opt-oxide.com, <http://www.opt-oxide.com>

Contents are things of 1-Feb-2013.


Fan-out PPMgSLT: Type O-T (Phase matching condition)

EXAMPLE of calculation
(Phase matching at around 50°C)


Type O




Type P




Type Q




Type R



Type S



Type T



Note:

- Above calculation are based on the following reference paper.
A. Bruner et al., Opt. Lett. Vol. 28, p. 194 (2003).
- Phase matching temperature would be different around $\pm 20^\circ\text{C}$ at visible light region and more at middle infrared region. That is because of the slight differences of refractive index between reference paper and real material. Please ask us detail information.

OXIDE

Oxide Corporation

1747-1 Makihara, Mukawa, Hokuto, Yamanashi 408-0302 JAPAN

Tel: +81-551-26-0022, Fax: +81-551-26-0033

Sales@opt-oxide.com, <http://www.opt-oxide.com>

Contents are things of 1-Feb-2013.